


Installation Instructions


SpeedBox 3.1 B.Tuning for TQ





A





- ▶ TQ HPR50
- ▶ TQ HPR60



STEP 1




STEP 2





B



► TQ HPR40

